

#Jenny



Finally I get this ebook, thanks for all these I can get now!

#Rio



Cool! I'am really happy

#Markus Jensen



I did not think that this would work, my best friend showed me this website, and it does! I get my most wanted eBook

#Hun Tsu



wtf this great ebook for free?!

#Che Salsa



My friends are so mad that they do not know how I have all the high quality ebook which they do not!

#Diego Butler



so many fake sites. this is the first one which worked! Many thanks

Opening and closing **Controls**

### Closing



The vehicle automatically detects the remote control when it is nearby or in the passenger compartment. Comfort Access supports the following functions:

- ▷ Unlocking/locking of the vehicle.
- ▷ Convenient closing.
- ▷ Convenient opening
- ▷ Unlocking of the trunk lid separately.
- ▷ Starting the engine.

Recessed grips in the interior trim of the trunk lid make it easier to pull down the lid.

**Danger of pinching**  
Make sure that the closing path of the trunk lid is clear; otherwise, injuries may result. 4  
Press the trunk lid down lightly. It is closed automatically.

### Emergency unlocking



Pull the lever in the cargo area. The trunk lid unlocks.

### Comfort Access

**The concept**  
The vehicle can be accessed without activating the remote control. All you need to do is to have the remote control with you, e.g., in your jacket pocket.

The vehicle automatically detects the remote control when it is nearby or in the passenger compartment. Comfort Access supports the following functions:

- ▷ To lock the vehicle, the remote control must be located outside of the vehicle.
- ▷ The vehicle cannot be unlocked or locked again for approx. the next five seconds.
- ▷ The engine can only be started if the remote control is inside the vehicle.

**Comparison to the standard remote control**  
The specified functions can be controlled by pressing the button or via Comfort Access. If you notice a brief delay while opening or closing the windows or retractable hardtop, the system is checking whether a remote control is inside the vehicle. Repeat the opening or closing procedure, if necessary.

### Unlocking



Pull the handle up, arrow 1. This corresponds to pressing the  button.

[Download PDF version of :](#)  
**Bmw Z4 E89 Workshop Manual**